

# Motorlager

*Bevi*

<u>Byggstorlek</u>	<u>Poltal</u>	<u>Lager drivsida</u>	<u>Lager fläktsida</u>
56	2-8	6201-2RS	6201-2RS
63	2-8	6202-2RS	6202-2RS
71	2-8	6203-2RS	6203-2RS
80	2-8	6204-2RS	6204-2RS
90	2-8	6205-2RS	6205-2RS
<hr/>			
100	2-8	6206-2RS	6206-2RS
112	2-8	6306-2RS	6306-2RS
132	2-8	6308-2RS	6308-2RS
160	2-8	6309-2Z	6309-2Z
180	2-8	6311-2Z	6311-2Z
<hr/>			
200	2	6312.C3	6312.C3
200	4-8	NU 312	6312
225	4-8	6313.C3	6313.C3
225	4-8	NU 313.C3	6313
<hr/>			
250	2	6313.C3	6313.C3
250	4-8	NU 315.C3	6315
280	2	6315.C3	6315.C3
280	4-8	NU 317.C3	6317.C3